

FULL 37-POINT INSPECTION LIST

	INSPECTION LEVEL						
	I	II	III	V	VI	VIII	
1. Choose the Inspection Site	X	X	X		X		
2. Approach the Vehicle	X	X	X		X		
3. Greet and Prepare Driver	X	X	X		X		
4. Interview Driver	X	X	X		X		
5. Collect the Driver's Documents	X	X	X		X	X	
6. Check for the Presence of Hazardous Materials/Dangerous Goods	X	X	X		X	X	
7. Identify the Carrier	X	X	X		X	X	
8. Examine Driver's License	X	X	X		X	X	
9. Check Medical Examiner's Certificate and Skill Performance Evaluation (SPE) Certificate (If Applicable)	X	X	X		X	X	
10. Check Record of Duty Status	X	X	X		X	X	
11. Review Driver's Daily Inspection Report (If Applicable)	X	X	X		X	X	
12. Review Periodic Inspection Report(s)	X	X	X	X	X	X	
13. Prepare Driver for Vehicle Inspection	X	X		X	X		
14. Inspect Front of Tractor	X	X		X	X		
15. Inspect Left Front Side of Tractor	X	X		X	X		
16. Inspect Left Saddle Tank Area	X	X		X	X		
17. Inspect Trailer Front	X	X		X	X		
18. Inspect Left Rear Tractor Area	X	X		X	X		
19. Inspect Left Side of Trailer	X	X		X	X		
20. Inspect Left Rear Trailer Wheels	X	X		X	X		
21. Inspect Rear of Trailer	X	X		X	X		
22. Inspect Double, Triple and Full Trailers	X	X		X	X		
23. Inspect Right Rear Trailer Wheels	X	X		X	X		
24. Inspect Right Side of Trailer	X	X		X	X		
25. Inspect Right Rear Tractor Area	X	X		X	X		
26. Inspect Right Saddle Tank Area	X	X		X	X		
27. Inspect Right Front Side of Tractor	X	X		X	X		
28. Inspect Steering Axle(s)	X			X	X		
29. Inspect Axle(s) 2 and/or 3 (Under Carriage of CMV)	X			X	X		
30. Inspect Axle(s) 4 and/or 5	X			X	X		
31. Check Brake Adjustment	X			X	X		
32. Inspect Tractor Protection System (This procedure tests both the tractor protection system and the emergency brakes.)	X			X	X		
33. Inspect Required Brake System Warning Devices	X	X		X	X		
34. Test Air Loss Rate	X	X		X	X		
35. Check Steering Wheel Lash	X	X		X	X		
36. Check Fifth Wheel Movement	X			X	X		
37. Complete the Inspection	X	X	X	X	X	X	